





## Pinwheel Yard Sign Assembly

Sign comes with pinwheel support already inserted into sign flutes.



Gently turn pinwheel support so that support tab faces out, towards you.

Carefully attach your pinwheel to the support tab by gently inserting the two prongs through the flutes on the top edge of the support tab.



Lastly, insert H-frame into flutes on bottom edge of sign.

